



URALCHEM NPK 21 10 10 3%S gran

(83019457)



3,34



1,05

Calibration faktor

1,14

Throw distance parameter

13,4

TS-System

Attention! An additional cross-check on a mobile test kit is recommended.

ZA-TS / ZG-TS	m			A	kg			%	%	kg	%	kg	%	kg	%
	1	2	3		1	2	3								
TS 1	15	38	600	A	1	500	1	21	500	1	31	500	18	-3	170
	16	39	600	A	1	500	1	20	500	1	30	500	18	-2	178
	18	43	600	A	1	720	1	19	600	1	29	500	19	0	219
	20	44	720	A	1	600	1	18	600	1	28	500	22	-1	206
	21	45	800	A	1	600	1	18	600	1	28	500	23	-2	203
	24	48	900	A	1	800	1	18	800	1	28	720	25	-1	231
TS 2	21	12	600	B	3	720	3	26	600	3	36	500	24	-2	170
	24	16	600	B	3	720	3	25	600	3	35	500	24	0	207
	27	21	600	D	X	500	1	23	600	1	33	500	24	2	262
	28	21	720	D	X	600	1	23	720	1	33	600	27	0	215
	30	23	800	B	3	900	3	23	800	3	33	720	29	0	215
	32	24	900	D	X	720	1	22	800	1	32	720	32	0	213
	33	25	900	D	X	720	1	22	800	1	32	720	32	0	228
TS 3	36	29	900	D	X	800	1	23	900	1	33	800	32	1	270
	24	13	600	C	2	720	2	24	600	2	34	500	27	-3	170
	27	17	600	C	3	720	3	21	600	3	31	500	28	0	212
	28	18	600	C	3	720	3	21	600	3	31	500	28	0	227
	30	20	720	C	3	800	3	21	720	3	31	600	31	-1	202
	32	22	800	C	3	900	3	21	800	3	31	720	33	-1	205
	33	23	800	C	3	900	3	21	800	3	31	720	33	0	217
36	25	900	C	3	900	3	21	800	3	31	720	36	0	232	