



Yara Balans 26 3 4 GLO

(83020518)



3,44



1,02

Calibration faktor

1,05

Throw distance parameter

16,0

ZA-TS

Attention! An additional cross-check on a mobile test kit is recommended.

ZA-TS / ZG-TS	[Icon]		[Icon]		[Icon]		[Icon]		[Icon]		[Icon]		[Icon]		[Icon]	[Icon]	[Icon]
	1	2	1	2	1	2	1	2	1	2	1	2					
TS 1	15	42	600	A	1	500	1	21	500	1	31	500	19	-4	170		
	16	42	600	A	1	500	1	20	500	1	30	500	19	-3	172		
	18	46	600	A	1	720	1	19	600	1	29	500	19	0	213		
	20	48	720	A	1	600	1	18	600	1	28	500	22	-2	201		
	21	49	720	A	1	600	1	18	600	1	28	500	22	-1	218		
	24	53	900	A	1	800	1	18	800	1	28	720	26	-2	223		
TS 2	21	18	600	B	3	720	3	26	600	3	36	500	24	-3	170		
	24	21	600	B	3	720	3	25	600	3	35	500	24	0	200		
	27	26	600	D	X	500	1	23	600	1	33	500	25	1	254		
	28	25	720	B	3	800	3	23	720	3	33	600	28	0	208		
	30	26	800	B	3	900	3	23	800	3	33	720	30	0	207		
TS 3	24	17	600	C	2	720	2	24	600	2	34	500	28	-3	170		
	27	19	600	C	3	720	3	21	600	3	31	500	28	-1	196		
	28	21	600	C	3	720	3	21	600	3	31	500	29	0	211		
	30	22	720	C	3	800	3	21	720	3	31	600	32	-2	191		
	32	25	720	C	3	800	3	20	720	3	30	600	32	0	217		
	33	26	800	C	3	900	3	21	800	3	31	720	34	-1	208		
	36	29	900	D	X	720	2	21	800	2	31	720	36	-1	224		